

LSX1502, LSX1502A,
LSX1502M, LSX1502MA

Woofer and HF Driver Wiring



Rev A
10/20/2008


CARVIN
carvinservice.com

Front of Crossover LSX1502, LSX1502M




LSX1502/M

Under Jack Plate



The LSX1502 Crossover is the same as the LSX1202. The difference is the speaker cabinet and speaker.

Connect to HF Driver




White (-)
Blue (+)



Driver HT151-16

The Blue and White Cables go to the Driver HT151-16. For a Replacement Driver go to Carvinservice.com click on "Parts"

Connect to Woofer



White (-)
Red (+)



Woofer PS12-8

The Red and White Cables go to the Woofer PS12-8. For a Replacement Woofer go to Carvinguitars.com


IMPORTANT: Don't mix up the two white cables, use as indicated in pictures above.

Front of Crossover LSX1502A/MA




LSX1502A/MA
Active Crossover

Side View



Connect to HF Driver



White (-)
Blue (+)



Driver HT151-16

The Blue and White Cables go to the Driver HT151-16. For a Replacement Driver go to Carvinservice.com click on "Parts"

Connect to Woofer



White (-)
Red (+)



Woofer PS15-8

The Red and White Cables go to the Woofer PS12-8. For a Replacement Woofer go to Carvinguitars.com